







SET FAN MOTOR IN PLACE ON THE 4 MOUNTING STUDS – MAKE SURE BUMP ON FAN MOTOR SITS INTO THE CUTOUT ON THE BRACKET (SEE BRACKET CUTOUT ON PREVIOUS PICTURE)



USE NUTS TO SECURE FAN MOTOR TO THE BRACKET AND INSERT PIN IN MOTOR SHAFT





ALIGN BLADE GROOVE TO SIT OVER PIN AND SECURE WITH LOCK RING



MULTIPLE SHROUDS USE THIS BRACKET SO THE PICTURES USED MAY NOT TO OF YOUR MODEL